







STERZO COMPONENTI
STEERING COMPONENTS

PIANTONI
STEERING COLUMNS

| | | |
|---|-------------------------|--|
|  | <p>RKD 257</p> | <p>Piantone sterzo M8x420mm.</p> <p><i>M8x420mm. Steering column</i></p> |
|  | <p>RKD 258</p> | <p>Piantone sterzo M8x490mm.</p> <p><i>M8x490mm. Steering column</i></p> |
|  | <p>RKD 258 A</p> | <p>Piantone sterzo M8x550mm.</p> <p><i>M8x550mm. Steering column</i></p> |
|   | <p>RKD 258 B</p> | <p>Piantone sterzo M8x490mm. Originale LGK 2005</p> <p><i>Original LGK 2005 M8x490mm. Steering column</i></p> |

STERZO COMPONENTI
STEERING COMPONENTS

PIANTONI
STEERING COLUMNS

| | | |
|--|----------------|--|
|  | RKD 259 | Piantone sterzo M10x490mm. <i>M10x490mm. Steering column</i> |
| | | |
| | | |
| | | |